



7. 하니스(벨매)를 조립하고 선의 위치를 그림과 같이 장착합니다. Connect the wiring harness, and arrange the wiring as in the image.



10. 스토퍼로 문의 높낮이를 조절합니다. Adjust the position of the door as needed, so that it looks like OEM filment when closed, by slightly loosening the main bolts.



8. 쇼바장착시 쇼바의 방향을 주의깊게 살핀후 먼저 한쪽부분을 장착합니다. Orient the strut so that the body of the strut is towards the car and the rod is towards the door.



11. 배선의 간섭이 없도록 주의 장착하고, 장착이 잘 되어있는지 테스트 합니다. Open and close the door, and test the vertical action of the doors, moving the door and tightening the bolt.



9. 문을 들어올린 후 쇼바의 나머지 부분을 장착합니다. Open the door. You will be able to open the door about 8 inches or so. When the door is completely open, raise the door completely. Use extreme caution at this stage as there is nothing holding the door up, so the heavy door must be supported 100% manually. Once the door is completely raised, attach the gas strut.

12. 웬더의 간섭부분을
오려냅니다.

Put the fender against the car, look to see where the inner lining of the fender will touch the hinge, and fold or cut out the inner part of the fender so that fender can be reinstalled.

